GAS AND ELECTRIC


FIRE ALARM INTERLIFT SIGNAL FROM F.A.C.P.
FLOW RESET ON GAS VALVE WHEN ALL ALARMS ARE NORMAL
DOWNSTREAM GAS SOLENOID VALVE
FROM ELECTRICAL PANEL
1-1/2W W X 1-1/2W L
1-1/2W W X 1-1/2W L
1-1/2W W X 1-1/2W L
FROM ELECTRICAL PANEL
1-1/2W W X 1-1/2W L
1-1/2W W X 1-1/2W L
1-1/2W W X 1-1/2W L