

NOTE: FOR NON-NAILABLE SUBSTRATES, FASTENERS MUST BE USED ONLY AT STUD FRAMEWORK LOCATIONS.