



NOTES:

1. FOR ALTERNATE CURB FLASHING REFER TO DETAIL U-12-C OR U-12-D.
2. POLYMER SEAM PLATES ARE REQUIRED IN LIEU OF SEAM FASTENING PLATES FOR MECHANICALLY-FASTENED ROOFING SYSTEMS OVER STEEL DECKS.
3. IF VERTICAL SPLICE IS NOT LOCATED AT CORNER, 6" (150 mm) WIDE PRESSURE-SENSITIVE ELASTOFORM FLASHING MUST BE CENTERED OVER FIELD SPLICE AT ANGLE CHANGE.
4. FASTENING PLATES MAY BE INSTALLED VERTICALLY.
5. APPLY PRIMER PRIOR TO INSTALLING SecurTAPE.
6. LAP SEALANT IS REQUIRED ON CUT EDGES OF REINFORCED MEMBRANE.

## U-5-B(OPTION #2) PRESSURE-SENSITIVE CURB FLASHING

