



## NOTES:

1. POSITION FASTENING PLATES 1/2" (13 mm) TO 1" (25 mm) FROM EDGE OF DECK MEMBRANE.
2. APPROXIMATELY 1/8" (3 mm) DIAMETER BEAD OF CUT-EDGE SEALANT IS REQUIRED ON CUT EDGES OF REINFORCED MEMBRANE.
3. FASTENING PLATES CAN BE INSTALLED VERTICALLY.
4. WHEN WALL FLASHING TERMINATION HEIGHT IS GREATER THAN 48" (1200 mm), IN ADDITION TO THE USE OF SURE-FLEX ADHESIVE THE WALL FLASHING MUST ALSO BE MECHANICALLY FASTENED TO THE WALL VERTICALLY OR HORIZONTALLY. REFER TO SURE-FLEX UNIVERSAL-12C OR 12D DETAIL.
5. REGARDLESS OF FLASHING TERMINATION HEIGHT, MECHANICAL SECUREMENT MAY BE UTILIZED IN LIEU OF ADHERING SURE-FLEX MEMBRANE. REFER TO SURE-FLEX UNIVERSAL-12E DETAIL.

PARAPET FLASHING < 48" (1200 mm)

SURE-FLEX  
UNIVERSAL - 12A