



NOTES:

1. FLASHING MEMBRANE FASTENED APPROXIMATELY 12" ON CENTER. IF FASTENER PENETRATES METAL COUNTERFLASHING, USE NEOPRENE WASHER OR APPLY WATER CUT-OFF MASTIC UNDER COUNTERFLASHING OR CAULK FASTENER HEAD.
2. APPROXIMATELY 1/8" (3 mm) BEAD OF CUT-EDGE SEALANT IS REQUIRED ON CUT EDGES OF REINFORCED MEMBRANE.
3. FOR CORNER FLASHING, REFER TO APPLICABLE SURE-FLEX UNIVERSAL-15C OR 15D DETAIL.

CURB FLASHING

SURE-FLEX
UNIVERSAL - 5A