



SCREW ATTACH BOTH ENDS OF  
 RUNNER TRACKS TO SHORT SECTION  
 OF STUD w/(2)#10-16 SCREWS  
 ON BOTH SIDES.

**CLARKWESTERN**  
 DESIGN  
 East Coast - Atlanta, GA      West Coast - San Diego, CA  
 20 Mansell Court East, Suite 350B      2035 Corte Del Nogal, Suite 165  
 Roswell, GA 30076      Carlsbad, CA 92011  
 Toll Free Phone: 877-832-3206

## BOTTOM TRACK SPLICE

RUNNER TRACK SPLICE – SCREW ATTACHED