



ATTACH TRACK TO STRUCTURE
 USING: (2)0.145"Ø P.D.F.'s @ EACH
 STUD LOCATION AND (4)0.145"Ø
 P.D.F.'s @ EACH JAMB LOACTION.

NOTE: INSIDE DIMENSION OF OUTER TRACK
 TO BE 1/8" MORE THAN STUD DEPTH.

DEEP LEG SLIP TRACK.
 MEMBER SIZE AS REQ'D
 PER DESIGN.

1/2" GAP TO
 ALLOW FOR VERTICAL
 DEFLECTION.

E.O.R.:
 VERIFY GAP DEPTH

NO ATTACHMENT
 TRACK TO TRACK.

DEEP LEG CAPPING TRACK.
 MEMBER SIZE AS REQ'D
 PER DESIGN.

(1)#10-16 SCREW AT
 EACH FLANGE.

WALL STUD

SIDE VIEW

CLARKWESTERN
 DESIGN

East Coast - Atlanta, GA
 20 Mansell Court East, Suite 350B
 Roswell, GA 30076

West Coast - San Diego, CA
 2035 Corte Del Nogal, Suite 165
 Carlsbad, CA 92011

Toll Free Phone: 877-832-3206

SLIP TRACK DETAIL
 TELESCOPING SLIP TRACK CONNECTION