



Note: If shingle nails penetrate Duro-Last membrane below the strip mastic/or 8-inch vertical climb, the back side of membrane shall have SB-240 applied on entire vertical climb.

1120

SHINGLE TIE-IN
 New Construction or Reroof
 © COPYRIGHT 1998

No
 Scale