



NOTE:

1. FOR HEAT WELDING LAPS USE 1 1/2" WELD WITH MACHINE AUTOMATIC MACHINE WELDER.
2. APPLY EVERGUARD® TPO AND PVC CUT EDGE SEALANT TO ALL CUT REINFORCED TPO AND PVC EDGES (REFER TO DETAIL MA/FA/BA 115).



FIELD OF ROOF SERIES

SIDE LAP DETAIL

DRAWING #

102

SYSTEM

MA

SCALE

N.T.S.

ISSUE/ REVISION DATE

7-01-11