



NOTE:

1. STONE/PAVER BALLAST (NOT SHOWN) REQ'D FOR BA SYSTEMS.
2. FOR INSULATION THICKNESS GREATER THAN 8" CONTACT GAFMC CONTRACTOR SERVICES FOR ALTERNATE MEMBRANE ATTACHMENT REQUIREMENTS.
3. ADD TOP EDGE TERMINATION IMMEDIATELY AFTER MEMBRANE INSTALLATION.
4. PLATES & SCREWS 6" O.C. REQ'D FOR BA SYSTEMS.
5. ADD EVERGUARD® TPO CUTEDGE SEALANT TO ALL CUT REINFORCED TPO EDGES (REFER TO DETAIL MA/FA/BA 115).