



CUT & BREAK PANEL IN FIELD.
BEND KNEE CAP TO PROPER ANGLE.
APPLY SEALANT & INSTALL KNEE
CAP & RIVET TO SECURE.

