



**NOTE:**

1. USE END CAP, LEFT 700-04 FOR TERMINATION.
2. USE END CAP, RIGHT 700-05 FOR TERMINATION.
3. USE METAL JOINT BLOCK, 500-07 WHERE ENDS OF PVC COVERS ARE BUTTED AGAINST EACH OTHER.
4. USE MOUNTING BRACKET, PLASTIC 500-08 FOR PVC RAIL MOUNTING.

DRAWN: SRB

DATE: 11/06/06

SCALE: 1:1

**SERIES 700-00  
TROLLEY GRIP HANDRAIL**

**TEPROMARK**  
INTERNATIONAL, INC.

1622 PAYNE STREET  
EVANSTON, IL 60201  
(800) 645-2622