



## Freezer Wall Base Connection

- Notes: 1. Install the cold side base angle after the panels are in place.  
 2. Fill voids between floor insulation and wall panels with one part urethane foam.