



PLAN

1. 6" SOWALL BRAND INSULATING PANEL
2. 10" ISOWALL BRAND INSULATING PANEL
3. 8" SOWALL BRAND INSULATING PANEL
4. FILL VOIDS WITH ONE PART URETHANE FOAM
5. W-23 ANGLE SET IN BUTYL CAULK AND FASTENED TO EACH PANEL 12" O.C.
6. CUT SPLINE GROOVE IN 10" PANEL TO MATCH 6" PANEL. FASTEN SPLINE TO GIRT WHERE POSSIBLE.