6"x6" COLUMN EMBEDDED INTO
CONCRETE FOUNDATION 12"

CONCRETE BASE BY OTHERS

DEFLECTOR PLATE AT
COLUMNS UTILIZED AS
DRAIN LEADERS

NO. 4 REBAR - 12" LONG
CENTERED ON COLUMN 3" AND 6"
FROM COLUMN BOTTOM

DEFLECTOR PLATE INSTALLATION NOTES:
1. DRILL 2" ⌀ HOLE 5" FROM TOP OF SIDEWALK.
2. CUT DRAIN HOLE SO THE BOTTOM IS 3" BELOW
   THE TOP OF DRILLED HOLE AND SIDES ARE
   FLUSH AS SHOWN.
3. INSTALL DEFLECTOR PLATE SO LIP IS OVER
   THE OUTSIDE OF COLUMN AND FASTEN
   WITH 2 - NO. 8 SCREWS.
4. CAULK THE INTERIOR OF THE COLUMN
   AROUND DEFLECTOR PLATE.

COLUMN BASE EMBEDDED IN CONCRETE