



WOOD FLOOR INSTALLATION SCHEME 4
DOUBLE GLUE DOWN INSTALLATION
OVER A WOOD SUBFLOOR

Double Glue Down installation over a wood subfloor:

1. Wood Floor
2. Bona R851 or R859 Adhesive – See trowel selection chart for your application
<http://resources.bona.com/books/wjds/#p=1>
3. Approved Sound control underlayment
4. Bona R851 or R859 Adhesive. 100F trowel used to adhere sound control underlayment to subfloor
5. Bona R540 moisture mitigator / primer (Optional – Used if additional moisture protection is required or as a primer for Advantech) <https://www.bona.com/en-US/Bona-Professional/Products/Adhesives/Bona-R540/>
6. Wood subfloor: wood / Plywood / OSB / Advantech