

## NOTES:

- 1. HP FASTENERS AND POLYMER SEAM PLATES ARE REQUIRED OVER STEEL DECKS.
- 2. END LAPS SHALL BE SPLICED USING 6" (15cm) WIDE SecurTAPE. REFER TO DETAIL U-2A.1.
- 3. OVERLAP THE ENDS OF FIELD APPLIED SecurTAPE A MINIMUM OF 1" (2.5cm). APPLY LAP SEALANT AT TAPE OVERLAPS 2" (5cm) IN ALL DIRECTIONS.
- 4. LAP SEALANT IS REQUIRED ON CUT EDGES OF REINFORCED EPDM MEMBRANE.

