

- 1. REMOVE ALL GRAVEL AT TIE-IN.
- 2. OVERLAY SURE-SEAL ELASTOFORM FLASHING WITH 6"(15cm) SURE-WHITE PRESSURE SENSITIVE FLASHING TO REDUCE HEAT GAIN ON TPO MEMBRANE
- 3. IF FLUTES ARE PERPENDICULAR TO THE TIE—IN DRILL A 3/8" (1cm) DIAMETER WEEP HOLE INTO THE BOTTOM FLUTES OF THE STEEL DECK ALONG THE PERIMETER OF THE TIE—IN 6" (15cm) MINIMUM TO 12" (30cm) MAXIMUM FROM THE SEAM FASTENING PLATE.
- 4. ON MECHANICALLY FASTENED SYSTEMS, HP-X FASTENERS AND PIRANHA PLATES OR HP-XTRA FASTENERS AND PIRANHA XTRA PLATES ARE REQUIRED TO BE USED FOR HOT AND/OR COLD METHOD OVER STEEL DECKS.
- 5. IF WATER PONDS OR FLOWS OVER TIE-IN FROM BUR SURFACE, USE DETAIL U-13B.

