

Figure 13c: Valley Product Application

Order of applying Certi-label® 2. Place pre-cut valley piece so shakes or shingles at valley: that cut-angle is positioned

- 1. Stop course line here
- . Place pre-cut valley piece so that cut-angle is positioned on the valley guide chalk line with tip on the course line.
- Select product of the required width to complete the course of Certi-label® shakes or shingles.