

Note: Consult your local building code official about the size and height (min 3") of the step flashing

Level reference line

To mark top of next course measure top down from the reference line

Cut the bottom of the shingle to maintain equal butt thickness with previous shingle in line

Cut the bottom of the dormer wall undercoursing shingle to reduce "bulging" (each successive course gets thicker) Top layer should extend 1/2" past the undercoursing

1/2"

Corner trim

Step flashing

Rafter

Fascia board

Figure 7b: Dormer Coursing

