



**NOTE:**  
 FOR NON-NAILABLE  
 SUBSTRATES, FASTENERS  
 MUST BE USED ONLY AT  
 STUD FRAMEWORK  
 LOCATIONS.

WATER BARRIER APPLIED  
 TO FACE OF SUBSTRATE  
 (BY OTHERS)

8

# OUTSIDE CORNER