

NOTE:
FOR NON-NAILABLE SUBSTRATES,
FASTENERS MUST BE USED ONLY
AT STUD FRAMEWORK LOCATIONS.

**NAILABLE SUBSTRATE
(BY OTHERS)**

ENVELOPE 2000®

**APPROVED
CONSTRUCTION
ADHESIVE
(BY OTHERS)**

NOTE:
IF MOISTURE BARRIER IS NOT
PRESENT, OMIT FLASHING
AND PLACE ADHESIVE DIRECTLY
ONTO NAILABLE SUBSTRATE.

5

INTERMEDIATE CONNECTION

