

## MC-17C

## **VALLEY TRANSITIONS**



## EXAMPLE OF FLAT OR LOW PROFILE TILE

THE VALLEY METAL MUST LAP ONTO THE TILE OF THE COURSE BELOW THE ROOF TRANSITION FLASHING



## EXAMPLE FOR HIGH PROFILE TILE

THE VALLEY METAL MUST LAP ONTO THE TILE OF THE COURSE BELOW THE ROOF TRANSITION FLASHING

LEAD SOAKER OR OTHER MALLEABLE MATERIAL SHOULD BE USED TO FORM A WATER FLOW TRANSITION FLASHING