


**NOTE:**

1. FOR HEAT WELDING LAPS USE 1-1/2" WELD WITH AUTOMATIC MACHINE WELDER AND 2" WELD WITH HAND WELDER.
2. T-JOINTS REQUIRED ON 60 & 80 MIL TPO AND 80 MIL PVC. (REFER TO MA/FA/BA 105)
3. APPLY EVERGUARD® TPO AND PVC CUT EDGE SEALANT TO ALL CUT REINFORCED TPO AND PVC EDGES (REFER TO DETAIL MA/FA/BA 115).

 <small>1301 Alpha Rd. Wayne, NJ 07470</small>	<b>FIELD OF ROOF SERIES</b>	<b>END LAP DETAIL</b> FOR 45 MIL TPO AND 60 MIL PVC MEMBRANE	<b>DRAWING #</b> 104	<b>SYSTEM</b> MA/FA/BA
			<b>SCALE</b> N.T.S.	<b>ISSUE/REVISION DATE</b> 7-01-11