



NOTE:

1. SCREWS/ ANCHORS 6" O.C. REQ'D FOR BA SYSTEMS. (IF BA SYSTEM USED IN A HIGH PRESSURE SITUATION ATTACH BAR 6" O.C.).
2. PLATES & FASTENERS MAY BE USED IN LIEU OF TERM BAR IN NON-PRESSURIZED SITUATIONS.
3. THIS DETAIL NEEDS TO BE USED FOR PRESSURIZED SITUATIONS.
4. APPLY EVERGUARD® TPO AND PVC CUT EDGE SEALANT TO ALL CUT REINFORCED TPO AND PVC EDGES (REFER TO DETAIL MA/FA/BA 115).

  <small>www.gaf.com</small> <small>1301 Alpha Rd. Wayne, NJ 07470</small>	PARAPET WALL & CURB SERIES	ALTERNATE WALL BASE TERMINATION DETAIL		<small>DRAWING #</small> 307	<small>SYSTEM</small> MA/FA/BA
		<small>SCALE</small> N.T.S.	<small>ISSUE/REVISION DATE</small> 7-01-11		