



NOTE:

1. FOUR CORNER CURB WRAP PIECES ARE NEEDED TO COMPLETE. VARYING SIZES MAY BE NEEDED TO COMPLETE
2. INSTALLATION OF FASTENERS & PLATES 12" O.C. APPROXIMATELY 6" (150 mm) FROM CORNER.
3. FLASHINGS MAY BE ADHERED OR INSTALLED DRY. SEE SPEC FOR DIMENSIONS.
4. APPLY EVERGUARD® TPO CUT EDGE SEALANT TO ALL CUT REINFORCED TPO EDGES (REFER TO DETAIL MA/FA/BA 115).

| | | | | |
|--|--|--------------------------------|-------------------------|--------------------------------|
|  <small>www.gaf.com</small> 1301 Alpha Rd. Wayne, NJ 07470 |  PARAPET WALL & CURB SERIES | CORNER CURB WRAP DETAIL | DRAWING # 325 | SYSTEM MA/FA/BA |
| | | TPO ONLY | SCALE N.T.S. | ISSUE/REVISION DATE 7-01-11 |