



NOTE:

1. STONE/PAVER BALLAST (NOT SHOWN) REQ'D FOR BA SYSTEMS.
2. EVERGUARD® ADHESIVE/GAF ASPHALT REQUIRED FOR FA SYSTEMS.
3. PLATES & SCREWS 6" O.C. REQUIRED FOR BA SYSTEMS.
4. APPLY EVERGUARD® TPO CUT EDGE SEALANT TO ALL CUT REINFORCED TPO EDGES (REFER TO DETAIL MA/FA/BA 115).

 <small>www.gaf.com</small> 1301 Alpha Rd. Wayne, NJ 07470	 SPECIAL CONSTRUCTION SERIES	TPO TO EXISTING EPDM	<small>DRAWING #</small> 609A	<small>SYSTEM</small> MA/FA/BA
			<small>SCALE</small> N.T.S.	<small>ISSUE/REVISION DATE</small> 7-01-11