



- NOTE:**
1. THIS DETAIL SHOULD BE USED ONLY WHERE THE DECK IS SUPPORTED BY THE OUTSIDE WALL.
 2. TO INSTALL AFTER THE BUILDING IS COMPLETED. THIS DETAIL IS USED TO RELIEVE STANDING WATER IN AREAS ALONG THE ROOF EDGE. ALL ROOF SURFACES SHOULD BE SLOPED TO DRAIN.
 3. ATTACH NAILER TO MASONRY WALL. REFER TO CURRENT FACTORY MUTUAL LOSS PREVENTION DATA SHEET 1-49.
 4. WOOD NAILERS MAY BE SLOTTED FOR VENTING WHERE REQUIRED.
 5. FLASHING FASTENED IN ACCORDANCE WITH EDGE DETAIL MB/BUR-20.
 6. DO NOT USE MASTIC WITH TORCHED APPLIED MEMBRANES. SET PRIMED FLANGE IN HEAT SOFTENED MEMBRANE ON TORCH APP AND HW SBS SYSTEMS.

 GAFGLAS <small>MEMBRANE SYSTEMS</small> RUBEROID <small>MEMBRANE SYSTEMS</small>	SCUPPER THRU ROOF EDGE DETAIL	DRAWING #	SYSTEM
		21	MB/BUR
		SCALE	ISSUE/REVISION DATE
		N.T.S.	10-01-10