



**NOTE:**

1. PROPERLY PREPARE OLD ROOF.
2. FLASHING AT PARAPET WALLS AND ROOF EDGES IS HANDLED IN THE SAME MANNER AS FOR NEW ROOF CONSTRUCTION. OLD FLASHINGS AND METAL EDGE STRIPS MUST BE COMPLETELY REMOVED AND NEW FLASHING AND METAL EDGE STRIPS INSTALLED
3. DO NOT APPLY RUBEROID TORCH OR RUBEROID HEATWELD MEMBRANES DIRECTLY TO STRATAVENT PERFORATED VENTING BASE SHEET. AT LEAST ONE PLY OF GAFGLAS #75 BASE SHEET OR 2 PLYS OF GAFGLAS PLY SHEETS MUST BE HOT MOPPED OVER STRATAVENT PERFORATED VENTING BASE SHEET BEFORE TORCH APPLYING RUBEROID MEMBRANES.
4. REFER TO MB/BUR SYSTEMS INSTALLATION REQUIREMENT SECTION.
5. WHEN THE MINIMUM DIMENSION OF THE ROOF EXCEEDS 90 FEET, TOP SIDE FIELD VENTING SHOULD BE USED IN ADDITION OF THE EDGE AND PARAPET WALL VENTING. ROOF VENTS ARE TO BE APPLIED AT THE RATE OF ONE VENT PER 1,000 SQUARE FT. OF ROOF AREA.



**GAFGLAS**  
MADE IN THE USA  
**RUBEROID**

**STRATAVENT® ELIMINATOR® PERFORATED**  
**VENTING DETAIL, RECOVER WITHOUT**  
**NEW INSULATION**

**DRAWING #**  
**36**

**SYSTEM**  
**MB/BUR**

**SCALE**  
 N.T.S.

**ISSUE/REVISION DATE**  
 5-01-09