



0 1" 2"
 SCALE: 1" = 2"

These drawings are published as an information guide only. These CAD drawings are intended as templates to assist the designer. They do not contain the full details required for construction and must be read in conjunction with the installation instructions on www.jameshardiecommercial.com. You should obtain architectural, engineering or other technical advice to assess the suitability of these drawings to the requirements of your particular project. James Hardie accepts no liability in respect to the use of these drawings.

For fastener specifications and complete installation instructions refer to appropriate documentation at www.JamesHardieCommercial.com.

DETAIL:

PLAN DETAIL – OUTSIDE CORNER TRIM

Reveal™
 1.05

Hardie Reveal™ Panel Vertical Siding

- Wood Framing
- OSB or Plywood Sheathing
- Pressure-Treated Wood Furring (Minimum 3/4" Nominal, 23/32" Actual Thickness) having specific gravity of 0.42 or greater
- Shown with Pan Head Screws into Furring

Rev. 5 (2014)

