



DOOR, FRAME, SADDLE & PIVOT HINGE BY OTHERS. COORDINATE INSTALLATION OF HINGE BOX W/WATERPROOFING APPLICATION.

PIVOT HINGE BOX SET IN 1/2" MIN. THICK BED OF KEMPEROL RESIN/SAND MORTAR. PRIME ALL CONTACT SURFACES W/KEMPEROL PRIMER.

METAL DOOR SADDLE SET IN CONTINUOUS BED OF KEMPEROL RESIN/SAND FILL. PRIME ALL CONTACT SURFACES W/KEMPEROL PRIMER.

STONE OR CONCRETE PAVER SET IN ACCEPTABLE MORTAR SETTING BED.

(1) PLY KEMPEROL MEMBRANE FLASHING EXTEND 2" MIN. HORIZONTALLY ONTO KEMPEROL FIELD MEMBRANE.

KEMPEROL FIELD MEMBRANE

DRAWING NO.

**M-10**

**PIVOT HINGE BOX FLASHING**

REVISION

10-15-2014

ISSUE DATE

03-01-2011

SCALE

N.T.S.

DRAWN BY

K.S.A.

