

- 1. Surface-mounted flashing may be sufficient in some mild climates. However, conceled or insert flashings such as "Z" metal or Stucco-type two-piece reglet and counter flashing or step flashing, are recommended in wet climates, particularly with stucco or other permeable cladding systems.
- 2. Dimensions shown are minimums and are intended to be appromate to allow for reasonable tolerances due to field conditions, and are practice.







