



- NOTES:
1. ATTACH WOOD NAILER TO WALL/DECK IN ACCORDANCE WITH FMRC GUIDELINES, AS PER SECTION 1-28, REGARDING WINDLOADS TO ROOF SYSTEMS AND DECK SECUREMENT.
  2. WOOD BLOCKING MAY BE SLOTTED FOR VENTING OF WET-FILL DECKS OR OTHER APPLICABLE CONSTRUCTIONS.
  3. REFER TO SMACNA RECOMMENDATIONS AND DETAILS REGARDING METAL THICKNESS.
  4. POLYGLASS RECOMMENDS ALL ROOF EDGE TERMINATIONS BE DESIGNED AND INSTALLED IN ACCORDANCE WITH ANSI/SPRI ES-1.

## SCUPPER DETAIL THRU RAISED EDGE (TYPICAL)

NUMBER:  
PG-EDGE-005

DATE:  
July 2011



Polyglass USA, Inc.  
1111 W. Newport Center Dr.  
Deerfield Beach, FL 33442  
www.polyglass.com