



- NOTES:
1. ATTACH WOOD NAILER TO WALL/DECK IN ACCORDANCE WITH FMRC GUIDELINES, AS PER SECTION 1-28, REGARDING WINDLOADS TO ROOF SYSTEMS AND DECK SECUREMENT.
  2. WOOD BLOCKING MAY BE SLOTTED FOR VENTING OF WET-FILL DECKS OR OTHER APPLICABLE CONSTRUCTIONS.
  3. POLYGLASS RECOMMENDS ALL ROOF EDGE TERMINATIONS BE DESIGNED AND INSTALLED IN ACCORDANCE WITH ANSI/SPRI ES-1.

## RAISED PERIMETER EDGE WITH METAL FLASHING

NUMBER:  
PG-EDGE-006

DATE:  
July 2011



Polyglass USA, Inc.  
1111 W. Newport Center Dr.  
Deerfield Beach, FL 33442  
www.polyglass.com