

# Typical ProLine Drain Installation Details

Note: Set all Quick Slope on structurally sound, flat sub-floor with fast-setting, self-curing thinset.  
Set the drain body level. Do not follow sub-floor if it is out of level.

