

# Typical Hot Mop Shower Pan Installation Details

Note: Also applicable for lead/copper pans, CPE membranes and other non-topical sheet and liquid waterproofing  
Set the drain body level. Do not follow sub-floor if it is out of level. Do not grout in cover. Cover must remain removable for maintenance.

