

Typical ShowerLine Drain Installation Details-Liquid Waterproofing

Note: Set all Quick Slope on structurally sound, flat sub-floor with fast-setting, self-curing thinset. Set the drain body level. Do not follow sub-floor if it is out of level.

