

RIMBOARD STARTER JOIST

Attach Rimboard to top plate with 8d nails @ 6" o.c. (when used for lateral shear transfer, nail to bearing plate with same nailing as required for decking.)

