



RFPI®-Joist blocking panel or x-bracing. Attach blocking panel (or Rimboard) to top plate with 8d nails @ 6" o.c. (when used for lateral shear transfer, nail to bearing plate with same nailing as required for decking)

> Continuous beveled wood plate required for slopes greater than 1/4/12. Code recognized slope connectors may be substituted. For slopes greater than 4/12 connectors are required to resist lateral thrust.

**Uplift connections** may be required.

L/4 (max.). Longer cantilevers may be acceptable as verified by appropriate software (e.g. Simpson Strong-Tie® Component Solutions™) or engineering analysis.