



**GENERAL NOTES:**

1. Provide insulation and finish systems to meet EIMA specifications. Installation of insulation and finish system shall be in accordance to EIMA's **Guide to Exterior Insulation & Finish System Construction**.
2. Installation of continuous Insulation shall meet the requirements of the Foam Sheathing Committee's Document **TER 1205-05 (latest version) Construction Details for the Use of Foam Plastic Insulating Sheathing (FPIS) In Light-Frame Construction**.
3. Install finish material in accordance with published standards for the specific material.
4. Cavity Insulation omitted from boxed jamb for clarity.
5. Provide air/water barrier compatible with selected finish material.
6. Wrap window rough opening with appropriate flexible flashing. Check EIMA guidelines.
7. Check with Underwriters Laboratories for specific air/water barrier systems.
8. Follow SFIA **Technical Guide for Cold-Formed Steel Framing Products** for specific depth, thickness, and spacing of structural studs.
9. Protect corner of interior gypsum panels with appropriate corner reinforcement.
10. Consult with specialty structural engineer for structural stud design.
11. Check local codes and mechanical engineer for vapor retarder type and location.
12. Maintain a minimum 3" flexible flashing return unto each adjacent surface.

DISCLAIMER: This detail must not be used without a complete evaluation by the owner's design professional to verify validity of the design.