

WHEN A WALL IS PARTIALLY OPEN STRAPPING MUST BE ATTACHED TO THE FACE OF ALL COLD-FORMED MEMBERS (CHANNEL, ZEE, EAVE STRUT OR GABLE ANGLE) AT MIDPOINTS OF BAY AND 5'-0" EACH SIDE OF COLUMN TO SUPPORTR THE WALL PANELS.

STK2000 WALL PANEL

EAVE STRUT
(By Others)

STRAPPING
(By Others)

CHANNEL
(By Others)

