


NOTES:

1. REMOVE ALL LEAD AND OTHER FLASHING BEFORE INSTALLING QUICK APPLIED PIPE SEAL.
2. PIPE SEAL MUST HAVE INTACT RIB AT TOP EDGE, REGARDLESS OF PIPE DIAMETER.
3. DECK FLANGES OF THE MOLDED PIPE SEAL SHALL NOT BE OVERLAPPED, CUT OR APPLIED OVER ANY ANGLE CHANGE.
4. AT THE CUT IN THE FIELD MEMBRANE, 60-MIL THICK CURED EPDM FLASHING OVERLAY MUST EXTEND 3" (76mm) BEYOND THE MOLDED PIPE FLASHING FLANGE ON 3 SIDES AND WITHIN 1" (25mm) OF THE EDGE OF THE FIELD MEMBRANE, AS SHOWN.
5. CENTER 9" (229mm) WIDE QUICK APPLIED UNCURED EPDM FLASHING OVER THE MEMBRANE SPLICE EDGE AND EXTEND 3" (76mm) BEYOND THE MEMBRANE OVERLAY, AS SHOWN.
6. SEAL ALL EDGES WITH CONTINUOUS LAP SEALANT.



**PRE-MOLDED QUICK-APPLIED PIPE SEAL WITH 90-MIL MEMBRANE OR 25 & 30 YEAR WARRANTIES**

 → EPDM MEMBRANE  
 → APPROVED SUBSTRATE  
 → SEE NOTE(S)

THERMOSET ROOFING SYSTEM  
**VGC-8.1B**