



NOTES:

1. FOR TPO, USE 6" (15cm) WIDE PS COVERSTRIP, FOR PVC USE 6" (15cm) WIDE REINFORCED PVC MEMBRANE, HOT AIR WELD ALL EDGES WITH MIN. 1-1/2" (4cm) PAST FASTENING PLATES

DIMENSIONS		cm	
(A)	6"	15	
(B)	32"	80	MAX.
(C)	12"	30	MAX.