



QUICKDRAIN LIQUID APPLIED WATERPROOFING KITS TECHNICAL SPECIFICATION

Job Name _____	Item # _____
Location _____	
Engineer _____	Contractor _____
PO # _____	Tag _____
Representative _____	

DESCRIPTION

Topical liquid waterproofing accessories shall be used in residential and commercial applications when creating a watertight shower pan, shower system, or wet room. Liquid membrane must be installed a minimum of 4" above the flood rim in a shower pan and can be used to waterproof walls within shower footprint or other surfaces with tile/stone application. Reinforcement accessories shall be used to bridge joints, create transitional seams or connection within the shower pan and shower system.

Liquid waterproofing accessories for use with any liquid waterproofing: Aqua Defense, Hydroban, 3295, Ardex 8+9, RedGard

WATERPROOFING KIT INCLUDES

- Reinforcement Fabric
- Reinforcement Collar
- Curb Covers (for curbed shower pans)
- Outside Corners (for ADA, curbless shower pans)
- Inside Corners

APPLICATIONS/USES

- Industrial, commercial and residential showers
- Gang showers
- Pet Showers

APPROVALS AND LISTINGS

Before installing QuickDrain USA system, check with your local building department/plumbing inspector to ensure compliance with the local building codes. QuickDrain USA LLC is not responsible for any conflicts with local building codes. QuickDrain USA LLC is not responsible for improper installation of any part of the assembly or the waterproofing membrane. Dimensions are subject to manufacturer's tolerance and can change without notice.



PRODUCT SELECTOR

SQUAREDRAIN LIQUID APPLIED WATERPROOFING KITS						
✓	Item Code	Reinforcement Collar Size	Kit Components			
			Curb Covers	Outside Corners	Inside Corners	Reinforcement Fabric
	SDLWP-SF	Small	2	-	4	1
	SDLWP-LF	Large	2	-	4	1
	SDLWP-ADA - SF	Small	-	2	2	1
	SDLWP-ADA - LF	Large	-	2	2	1

Access BIM/Revit content through www.quickdrainusa.com