Boral Steel® Architectural Details are divided into three (3) categories based on the install method used:

BATTEN (Panel is exposed fastened & mounted onto a wood 2x2 batten or steel hat channel)

DIRECT (Panel is exposed fastened & mounted Direct-to-the roof-deck)

GRANITE-RIDGE Shingle (Panel is hidden fastened & mounted Direct-to-the roof-deck)

Headwall: Install Headwall flashing to sit tightly to panel and wall. install a bead of sealant between Headwall and panel. Fasten to structure with appropriate fasteners.

Panels: Install panel to interlock fully with previous course. Fasten to structure with fasteners to penetrate decking a minimum $\frac{3}{8}$ ", seven (7) per panel.

Boral Steel "Z" Bar: Fasten with appropriate fastener 12" O.C. max. Seal top with approved sealant

Panels: Cut "Short Course" as needed to fit panel lay-out. Fasten to structure with appropriate fasteners.

Roofing Underlayment: Turn up 3" minimum at headwall.

Profiles: GRANITE-RIDGE Shingle

GRANITE-RIDGE Shingle Headwall with Z-Bar

Boral Steel Stone Coated Roofing 7575 Irvine Ctr Dr Suite 100, Irvine, CA 92618

Drawings are not to scale