



This symbol can be used for ironer model F32118-2 all heat types










This symbol can be used for ironer model F32130-2 all heat types



This symbol can be used for ironer model F32138-2 all heat types

Legend of connection symbols

- | | | | |
|---|-----------------------------|---|--|
|  | Main electrical connection |  | Compressed air inlet connection |
|  | Gas inlet connection |  | Steam inlet connection (optional on washers) |
|  | Exhaust vent connection |  | Steam condensate return connection |
|  | Cold water inlet connection | | |

All clearances shown are minimum recommended