

## CORNERS ARE TYPICALLY A RECOMMENDED STARTING POINT FOR INSTALLATION. USE TABLE BELOW FOR ANGLES 90° AND 45°. DETAILS FOR ANY OTHER ANGLE AVAILABLE BY REQUEST.

### SIDE MOUNT CORNER CONDITIONS


|                       | ROUND TOP RAIL | FLAT TOP RAIL | WOOD TOP RAIL |
|-----------------------|----------------|---------------|---------------|
| 90° OUTSIDE<br>CORNER |                |               |               |
| 90° INSIDE<br>CORNER  |                |               |               |
| 45° OUTSIDE<br>CORNER |                |               |               |


# **TOP MOUNT CORNER CONDITIONS**

|                       | ROUND TOP RAIL | FLAT TOP RAIL | WOOD TOP RAIL |
|-----------------------|----------------|---------------|---------------|
| 90° INSIDE<br>CORNER  |                |               |               |
| 90° OUTSIDE<br>CORNER |                |               |               |
| 45° INSIDE<br>CORNER  |                |               |               |


# ALL AGS STAINLESS, INC. CLEARVIEW® RAILING SYSTEMS CAN BE MODIFIED TO ACCEPT GLASS PANELS


CONTACT AGS FOR ADDITIONAL CUSTOMIZATION OPTIONS 888-842-9492 OR info@agsstainless.com















#### SIDE MOUNT RECOMMENDED INSTALLATION



HARDWARE

<u>-</u>4-

· ·

4星(

