



"SS-04-1" BASE ROOF FLASH

ERECTOR NOTES:

1. START BASE ROOF FLASH @ EAVE & PROCEED UPWARDS CAULKING AND LAPPING EACH 4" MIN.
2. "A" DIMENSION VARIES DUE TO CONSTRUCTION VARIATIONS.



BOX 515 RAILROAD STREET
 SANDY LAKE, PENNSYLVANIA 16145-0515
 PHONE: 800-245-0396 ° FAX: 724-376-3864

"Fss-18" Standing
 Segm Details

Base Roof Detail

DRAWN BY: RW

DATE: 7-13-00

DRAWING NO.

CHECKED BY: CANON

DATE:

FSS18-14