




CHORAL RISER STYLE 'A'
(STORAGE SET-UP)



TOP VIEW




FRONT VIEW




SIDE VIEW


CHORAL RISER STYLE 'A'
(PERFORMANCE SET-UP)



TOP VIEW




FRONT VIEW




SIDE VIEW


CHORAL RISER STYLE 'B'
(STORAGE SET-UP)



TOP VIEW




FRONT VIEW




SIDE VIEW


CHORAL RISER STYLE 'B'
(PERFORMANCE SET-UP)



TOP VIEW



FRONT VIEW



SIDE VIEW