



## TECHNICAL INFORMATION

### INFORMATION ON CLEANING AND CARE OF COMPONENTS LAMINATED WITH RENOLIT EXOFOL FILMS

#### GENERAL

**RENOLIT EXOFOL** films are multi-layer films with a transparent surface layer. This protects the intermediate coloured layer, and in the case of wood décors, the printed layer, from adverse exposure to sunlight and weather conditions.

#### CLEANING

Components laminated with **RENOLIT EXOFOL** films can be easily cleaned with water and a soft sponge or cloth. Contamination that is not caused by natural weather conditions should be removed immediately. If required, dilute solutions of neutral detergents, washing up liquid or window cleaning agents may also be used.

#### NO USE OF ABRASIVE DETERGENTS

Such cleaning agents are not suitable for the cleaning of components laminated with **RENOLIT EXOFOL** films.

#### NO USE OF SOLVENT-BASED DETERGENTS

The solvent content of solvent-based detergents will damage the film surface and are therefore unsuitable. This is also the case of ethanol in both its pure and slightly diluted forms.

**ADVICE:** Always comply with the detergent usage instructions. Do not use the detergent if there is any doubt as to its suitability. Only ever use neutral cleaning agents (soaps), washing-up liquids or detergents in non-concentrated form that are specifically appropriate and approved for use on the plastic material PMMA (polymethylmethacrylate).

This technical information sheet represents our latest state of knowledge and shall inform without obligation. The herein stated details do not release the manufacturer using our films from their own inspections and tests, which must correspond with the relevant national guidelines for its intended purpose. It is the duty of the customer to determine if the purchased product is suitable for its intended purpose.

**The recipient of this information shall neither forward nor publish the content or parts of it to third parties without prior written consent of RENOLIT.**

Stand 12/2020